




单色说明书 折后尺寸: 92*136mm 纸材质: 120g 铜版纸 折法: 风琴折











内容并妥善保管好此保修卡。本公司出品的产品在正常使用情况下如发生非人为故障,

1.人为因素造成的损坏,包括不按说明书操作引起的故障,或因保管不善造成产品撞击、

客户可凭此保修卡及有效购买凭证向原经销商申请保修服务。

2.私自拆卸自行维修和改装或由非特约维修站点维修所引起的故障;

跌落、折弯等引起的损坏(产品表面有明显磨损痕等);


3.用户无法提供产品保修卡及有效购买凭证;


4.对购买记录或产品信息等人为涂改的;


但不包含以下情况:


5.超出产品保修期限。


12



















ALSEYE®	Product Warranty Card
中姓名:	USER NAME: CONTACT NUMBER: PRODUCT NAME: PRODUCT MODEL: DATE OF PURCHASE:
(注:用户未能提供购买日期凭证者以产品出厂日期为准)	(Note: If the user fails to provide the certificate of purchase date, the factory date shall prevail) Thank you for purchasing and using ALSEVE heat dissipation series products. In order to enjoy

better service, please read the following contents carefully and properly Keep this warranty card safe.In case of non-human fault of the products produced by our company under normal use,

(obvious wear marks on the product surface, etc.);

- 2. Failure caused by disassembly, maintenance and modification by oneself,
- or maintenance by non-special maintenance sites;
- 3. The user cannot provide the product warranty card and valid purchase voucher; 4. Artificially alter purchase records or product information;
- 5. The warranty period of the product is exceeded;

